

for FOSC 400 D5 Closures

1.0 General Product Information

The FOSC ACC D Pole Mount kit supplies a bracket for mounting a FOSC 400 D5 Fiber Optic Splice Closure to a pole or a wall.

2.0 Kit Contents

- One metal bracket
- 2 screw anchors
- 2 lag bolts
- 2 mounting bolts/nuts

3.0 Required Materials

A wrench or ratchet is needed for installing the lag bolts used to attach the bracket to a wooden pole or wall. Large tie wraps, metal straps, or hose clamps can be used to mount the bracket to a concrete pole.

4.0 Installation Instructions

1. Install the bracket on the pole or wall as shown in Figure 1 using supplied screw anchors and lag bolts.
2. Place the FOSC 400 D5 closure on the bracket as shown in Figure 2.

Note: *The base-to-dome clamp on the closure should be positioned so that its handle does not interfere with the bracket. If necessary, reposition the clamp.*

3. Secure the closure to the bracket by installing two mounting bolts through the holes in the tabs on the closure base and dome. Secure in place with supplied nuts.



Figure 1




Figure 2

CommScope Inc.

Patents:

<http://www.commscope.com/ProductPatent/ProductPatent.aspx>

Contact us at Support Center:

<http://www.commscope.com/SupportCenter>

FOSC 400, CommScope logo and CommScope are trademarks.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, CommScope makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. CommScope obligations shall only be as set forth in CommScope' Standard Terms and Conditions of Sale for this product and in no case will CommScope be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of CommScope products should make their own evaluation to determine the suitability of each such product for the specific application.